

Installation and Instructions for Use

IMPORTANT: These instructions apply only to installing your StemCaptain on a threadless style headset stem on a bike that already has a properly installed fork, headset and stem. To remove your existing stem cap, the stem cap center bolt is the only fastener that needs to be removed; no loosening of the stem bolts or other operations should be required. If the stem cap does not come out of the stem when its center bolt is removed, your steering system could be improperly set up, or you have an incompatible style headset. If you encounter any difficulties, consult your local bike store or contact info@stemcaptain.com with any questions before proceeding. For additional instruction on StemCaptain installation, you can view a video at www.stemcaptain.com/install.video. If you are installing or setting up a fork, headset or stem, follow the manufacturers instructions or consult your local bike store. Thanks for your attention to safety and see you on the trail!

1. Remove center bolt from existing stem cap by turning counter clockwise.



2. Remove stem cap from stem. **IMPORTANT:** verify there is at least 2 mm clearance between the top of the steer tube and top of stem or spacer. If less than 2 mm, see notes below.



3. Replace stem cap with StemCaptain base unit.



4. Install bolt in center of StemCaptain base and tighten by turning the bolt clockwise. **DO NOT OVER TIGHTEN!** Bolt only requires 15-20 in/lbs of torque.



5. To adjust time, pull out slightly on the adjustment spindle and rotate to adjust. Push spindle back in after adjustment. **NOTE:** remove plastic spacer tab (if applicable) attached to adjustment spindle to activate.



6. Accurately align clock to the pocket in the base unit. For proper insertion, make sure the rubber gasket is engaged all the way around base before pushing down.



7. Push alternately on opposite sides of the clock until properly seated.

8. Peel protective film from clock face (if applicable).

9. Enjoy the beauty and convenience of your new StemCaptain!

For additional info and installation video, please visit our website @ www.stemcaptain.com.

Questions or feedback? Please contact us at: info@stemcaptain.com

Notes:

- If clearance between top of steer tube and top of stem is less than 2 mm, a spacer is required for proper mounting and function.
- When installing or replacing your fork, headset or stem, be certain to follow the corresponding manufacturer's instructions for proper setup.
- The back plate on the clock is removable for battery replacement and service. Batteries can be purchased at www.stemcaptain.com.